

## 2. The 12 volt panel

Use the up and down buttons to toggle through your water tank gauge and your battery voltage. The following functions are available on the 12v panel.

Top row functions from left to right:

- Navigational Instruments
- Auto pilot
- Stereo system
- Anchor windlass
- Bilge pump in saloon

Middle row functions from left to right:

- Fresh water pump
- Shower drain
- Panel light
- Not in use
- Fridge

Bottom row functions from left to right:

- F1 - Not in use
- F2 - Not in use
- F3 - Not in use
- F4 - Not in use
- F5 – Cockpit light

Long press button for restart indication when screen is freezes



Toggle this button to check your batteries voltage, waste and water tank levels