10. Bilge Pumps

Yacht is equipped with one manual and one electric bilge pumps. The electric pump is operated by a switch on the 12v panel . Electric pump is located under the floor betwee saloon table and central seats.



The manual pump is located in the cockpit.





Bilge pump button